Paperflex Signs Installation Guide

Mounting of Paperflex Signs

1.
The back plate is screwed or taped to the wall.

2.
The sign is placed onto the back plate.

3.
Done.

Afmontering af individuelle skilte

1.
Installed sign.

2.
Place the magnetic key at the center of the sign.

3.
The lock is released from the sign plate, and the sign is slid to the side

4.
Skiltet tages af.

dansign